

KTO 111



?? ????? : 11100.0-00 THERMOSTAT SWITCH KTO 111 ????? ?????? ?????? (Heater) ??? ? ????? ?? ?????? ??? ?? ?? ??? ??????. ?????? ????
????? : 7 K (± 4 K tolerance) ????? ?????? : thermostatic bimetal ????? ?????? : IP 20 / II

???? ?????: ????? ????? ?????
????

[?? ????? ?????? ??? ?????? ??????](#)

???

The mechanical NC thermostat opens when the temperature rises and is used to control heaters or to switch signal transmitters when the temperature undershoots. The use of push-in terminals prevents the supply lines from coming loose.

- Fixed supply lines thanks to push-in terminals
- Time saving thanks to tool-free connection
- Large adjustment wheel enables convenient adjustability
- Optimized air inlets
- Can be used at altitudes of up to 5000 meters

???????? ??

???? ????? ??? ???? ????? ???? ?????.

// //